OWNER'S MANUAL

THE ART OF START™

TERMS OF USE

INSTALLER TERMS OF USE

Automotive Data Solutions Inc. ("ADS") products are strictly intended for installation by Certified Technicians who are employed by a registered business specialized in the installation of automotive aftermarket electronics products. Prior to beginning installation of an ADS product in a vehicle, it is the Certified Technician's responsibility to review the most current Product Guide, Install Guide and vehicle-specific notes available in Weblink®. ADS is not responsible for any damages whatsoever, including but not limited to any consequential damages, incidental damages, damages for loss of time, loss of earnings, loss of profit, commercial loss, loss of economic opportunity and the like that may or may not have resulted from the use, misuse, improper installation or operation of its products. Purchasers sole contractual remedy is refund of the purchase price of the ADS product(s). ADS reserves itself the right to suspend any Weblink® account without notice and decline to offer technical support to non-Certified Technicians, non-compliant Certified Technicians or end users.

END USER TERMS OF USE

ADS products are designed to remote start vehicles from a distance. In order to ensure your iDatastart system meets all safety regulations and operates as intended by the manufacturer, please follow the usage recommendations below:

• DO NOT use this product for any purpose other than its intended usage.
• DO NOT remote start a vehicle in an indoor or enclosed area (i.e. garage). Exhaust fumes are extremely dangerous and can cause personal injury or death. Install carbon monoxide detectors in every living area that can be exposed to vehicle exhaust fumes.
• DO NOT remote start a vehicle while it is being serviced. Follow the Valet Mode procedure as outlined in your Owner's Manual.
• DO NOT remote start a vehicle in gear.
• DO NOT remote start a vehicle with the key in the ignition.
• DO NOT remote start a vehicle left unattended with open windows, unlocked doors or open convertible top.
• DO NOT allow children handle or operate long range remotes.
• ALWAYS engage your emergency brake prior to exiting your vehicle. This may limit motion if the vehicle is accidentally started in gear.

• AVOID remote starting your vehicle while passengers or pets are on board. This may increase the risk of shifter being put in gear after vehicle has been remote started.
• AVOID parking your vehicle on an inclined surface or an area surrounded by obstacles. For manual vehicles, ALWAYS ensure the Reservation Mode sequence, as outlined in your Owner's Manual, is correctly engaged prior to the next remote start.
• AVOID delaying the inspection of your iDatastart system in the event of malfunction. Immediately contact a Certified Technician to ensure that installation or defective equipment is properly addressed.

REMOTE OVERVIEW

Your iDatastart remote start system may include one or both long-range remotes listed below.
Please take a moment to familiarize yourself with their general features.



REMOTE MODEL	R240G
Technology	LoRa 2-WAY
Communication / Max. Range	2-Way / 1 Mile
Buttons	5
Transmit confirmation (TX)	Top RGB LED
Receive confirmation (RX)	Top RGB LED + Chime
Battery type	Built-in rechargeable battery with charging via USB-C
Avg. battery life (per charge)	21 days
Warranty	1 year

REMOTE COMMANDS & CONFIRMATIONS

Thanks to their multiplexing technology, iDatastart remotes can pack over 30 functions using only 5 buttons. In order to get the most out of your remotes, please take a moment to get acquainted with the following functions below:

NOTES:
1. All functions must be enabled by an Authorized Dealer during installation to be functional on remote
2. Non-highlighted icons = Press & release button
3. Highlighted (grey) icons = Press & hold button for 2.5 seconds
4. Coma (,) between icons = Press buttons one after the other
5. Plus (+) between icons = Press buttons together
6. Timeout between each button press = 3 seconds

COMMAND	**Lock & Arm**
BUTTON	
DESCRIPTION	Secures your vehicle by locking the doors and arming the alarm.
CONFIRMATION	1 chime + 1 flash

COMMAND	**Unlock & Disarm**
BUTTON	
DESCRIPTION	Accesses your vehicle by unlocking the doors and disarming the alarm.
CONFIRMATION	2 chimes + 2 flashes

COMMAND	**Query**
BUTTON	
DESCRIPTION	Queries system status

COMMAND	Panic
BUTTON	
DESCRIPTION	Triggers the panic siren.
CONFIRMATION	1 chime + 1 flash

COMMAND	Trunk Release*
BUTTON	
DESCRIPTION	Releases the trunk or hatch.


COMMAND	Engine Start/Stop
BUTTON	
DESCRIPTION	Starts and stops the engine.
CONFIRMATION	4 chimes + 4 flashes (Button LEDs will also flash intermittently while engine is running)


COMMAND	AUX 1
BUTTON	
DESCRIPTION	To be completed by Authorized Dealer if applicable

COMMAND	AUX 2
BUTTON	
DESCRIPTION	To be completed by Authorized Dealer if applicable

COMMAND	AUX 3
BUTTON	
DESCRIPTION	To be completed by Authorized Dealer if applicable

COMMAND	AUX 4
BUTTON	
DESCRIPTION	To be completed by Authorized Dealer if applicable

COMMAND	Silent Lock
BUTTON	
DESCRIPTION	Disables the vehicle’s horn and alarm siren.

COMMAND	Silent Unlock
BUTTON	
DESCRIPTION	Disables the vehicle’s horn and alarm siren.

COMMAND	Valet Mode ON/OFF
BUTTON	
DESCRIPTION	Turns off remote start and security features when servicing your vehicle or valet parking. Keyless entry features remains functional.
CONFIRMATION	•1 chime ON •2 chimes OFF

COMMAND	Runtime Extend
BUTTON	
DESCRIPTION	Seamlessly extends your engine runtime without restarting your vehicle.

COMMAND	Mute ON/OFF
BUTTON	
DESCRIPTION	Disables the vehicle’s horn and alarm siren even when alarm is triggered. Remote will still receive alarm notification.
CONFIRMATION	•1 chime ON •2 chimes OFF

COMMAND	Shock Sensor ON/OFF
BUTTON	
DESCRIPTION	Disables shock sensors if installed.
CONFIRMATION	•1 chime ON •2 chimes OFF

COMMAND	Ignition Lock ON/OFF
BUTTON	
DESCRIPTION	Vehicle Ignition must be ON to toggle this feature. Automatically locks doors when engine is running.
CONFIRMATION	•1 chime ON •2 chimes OFF

COMMAND	Passive Lock & Arm ON/OFF
BUTTON	
DESCRIPTION	Automatically locks and arms your vehicle 60 seconds after you unlock it.
CONFIRMATION	•1 chime ON •2 chimes OFF

COMMAND	Turbo ON/OFF
BUTTON	
DESCRIPTION	Cools down your turbo before turning the engine off. Programmable runtime from 30 seconds to 4 minutes.
CONFIRMATION	•1 chime ON •2 chimes OFF

COMMAND	Weather Start ON/OFF
BUTTON	
DESCRIPTION	Sets your vehicle to automatically remote start every 2, 3 or 4 hours (programmable) or from a temperature sensor sold separately.
CONFIRMATION	•1 chime ON •2 chimes OFF

COMMAND	Mute Remote ON/OFF
BUTTON	
DESCRIPTION	Disables the chime when pressing any button on your remote.
CONFIRMATION	•1 chime ON •2 chimes OFF

PROGRAMMING A NEW REMOTE

iDataStart remotes can be added or removed using the iDataGO mobile app.

CHARGING THE REMOTE'S BUILT-IN BATTERY

Your iDatastart remote has a built-in rechargeable battery that can be charged using USB

To charge your remote using USB:
1. Insert the USB cable into the remote’s USB port.
2. Connect the USB cable to the USB power adapter.
3. Plug the USB power adapter to a power outlet.
4. The LEDs will turn on to indicate that the remote is charging.

ADJUSTING ENGINE RUNTIME SETTINGS

The engine runtime for remote start can be adjusted in the iDataGO mobile app.

KEY TAKEOVER FOLLOWING REMOTE START

The ‘key takeover’ procedure ensures that your engine does not shut down upon entering the vehicle, during the programmed remote start runtime. To prevent your vehicle from shutting down, complete the steps below within the programmed delay time (45 seconds, 90 seconds, 3 minutes or 4 minutes):

For Standard Key Vehicles
1. Unlock and enter vehicle
2. Close doors
3. Insert key into ignition and turn ignition to ON position
4. Press foot brake

For Push-To-Start Vehicles
1. Unlock and enter vehicle with valid smartkey
2. Close doors
3. Press foot brake

NOTE: This feature may not be supported on some vehicles. If available, the programmed ‘key takeover’ delay time will be communicated to you by your iDatastart Authorized Dealer at the time of installation.

REMOTE START TROUBLESHOOTING

If your iDatastart remote fails to start the vehicle, the parking lights will flash three times immediately, then flash a number of times corresponding to the error code. The remote LED will also flash the corresponding number of times. Refer to the table below for the diagnostic information and recommended solution.

# OF PARKING LIGHT FLASHES	# OF REMOTE LED FLASHES	DIAGNOSTIC	SOLUTION
3 + 1	1	Need to learn tach	n/a
3 + 2	2	Key in ignition at ON position	Remove key from ignition
3 + 3	3	Door is open	Close door
3 + 4	4	Trunk is open	Close trunk
3 + 5	5	Brake is detected	Release brake
3 + 6	6	Hood is open	Close hood
3 + 7	7	Reservation not done (manual only)	Perform reservation procedure
3 + 8	8	Tach failure	Contact Authorized Dealer
3 + 9	9	VSS detected (vehicle in movement)	Contact Authorized Dealer
3 + 10	10	System is in Valet Mode	Exit Valet Mode
3 + 11	11	Can communication failure	Contact Authorized Dealer
3 + 12	12	Can communication failure	Contact Authorized Dealer
3 + 13	13	Bypass error	Contact Authorized Dealer
3 + 14	14	No Pitstop or Takeover available	Contact Authorized Dealer
3 + 15	15	Module overheat protection	Contact Authorized Dealer

VEHICLE SHUTDOWN TROUBLESHOOTING

If the remote start sequence has been completed and the vehicle shuts down, the vehicle's parking lights will flash 4 times immediately, then flash a number of times according to the errors below:

# OF PARKING LIGHT FLASHES	DIAGNOSTIC	SOLUTION
4+1	No engine rev detected	Contact Authorized Dealer
4+3	Brake detected	Release brake
4+4	Hood open detected	Close hood
4+5	Engine revving over 3000 RPM	Check your accelerator pedal
4+6	Glow plug error	Contact Authorized Dealer
4+7	Vehicle speed sensor error	Contact Authorized Dealer
4+8	'Check Engine' light detected	Clear 'Check Engine' code
4+9	Low fuel detected	Add fuel
4+10	Door open detected	Close door
4+11	CAN communication failure	Contact Authorized Dealer
4+12	Key synchronisation failure	Contact Authorized Dealer
4+13	Bypass error	Contact Authorized Dealer
4+14	No Pitstop or Takeover available	Contact Authorized Dealer
4+15	Module overheat protection	Contact Authorized Dealer

LIMITED LIFETIME WARRANTY

Automotive Data Solutions Inc. ("ADS") warrants to the original purchaser of the iDatastart product that the following components product shall be free of defects in material and workmanship under normal use and circumstances:

Control module and installation harnesses
For as long as the original purchaser owns the vehicle in which it was originally installed.

Remote transmitters and antenna
For the period of one (1) year from the date of original installation.
Excludes battery replacement.

In the event of any product malfunction during the Warranty period, the original purchaser must return to the Authorized Dealer where it was originally purchased with the original proof of purchase. If a malfunction is

detected, the Authorized Dealer will elect to repair or replace the product at its discretion. Labor costs may be applicable and are at the discretion of the Authorized Dealer.

The Limited Lifetime Warranty is automatically void if:
• An original proof of purchase is not provided when servicing the product during the warranty period;
• The date code and/or serial number is defaced, missing, or altered;
• The iDatastart product is transferred to another vehicle;
• The vehicle in which the product was originally installed is transferred to a new owner.

ADS is not responsible for any damages whatsoever, including but not limited to any consequential damages, incidental damages, damages for loss of time, loss of earnings, commercial loss, loss of economic opportunity and the like that may or may not have resulted from the installation or operation of an iDatastart product. Purchasers sole contractual remedy is refund of the purchase price of the ADS product(s).

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

IC STATEMENT

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-3 (B)/NMB-3(B)

SAR INFORMATION STATEMENT

Your wireless REMOTE CAR STARTER (TWO WAY) is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and
thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless REMOTE CAR STARTER (TWO WAY) employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 4.0 W/kg. Tests for SAR are conducted with the REMOTE CAR STARTER (TWO WAY) transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the REMOTE CAR STARTER (TWO WAY) while operating can be well below the maximum value. This is because the REMOTE CAR STARTER (TWO WAY) is designed to operate at multiple power levels so as to use only the power required to reach the network.

In general, the closer you are to a wireless base station antenna, the lower the power output. Before a REMOTE CAR STARTER (TWO WAY) model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model REMOTE CAR STARTER (TWO WAY) when tested for use at the extremity is 0.030W/Kg.

While there may be differences between the SAR levels of various REMOTE CAR STARTER (TWO WAY) and at

various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model REMOTE CAR STARTER (TWO WAY) with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model REMOTE CAR STARTER (TWO WAY) is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/oet/fccid after searching on the Grantee Code: 2AEPJ. Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at http://www.wow-com.com.*

In the United States and Canada, the SAR limit for REMOTE CAR STARTER (TWO WAY) used by the public is 4.0 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

This device complies with FCC and ISED 10-g extremity SAR requirements when the device is used at 0 mm separation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.