OWNER’S MANUAL

THE ART OF START™

TERMS OF USE

INSTALLER TERMS OF USE

Omegalink systems are strictly intended for installation by Certified Technicians who are employed by a registered business specialized in the installation of automotive aftermarket electronics products. Prior to beginning installation of an Omegalink system in a vehicle, it is the Certified Technician’s responsibility to review the most current Product Guide, Install Guide and vehicle-specific notes available in Weblink®. Omegalink is not responsible for any damages whatsoever, including but not limited to any consequential damages, incidental damages, damages for loss of time, loss of earnings, loss of profit, commercial loss, loss of economic opportunity and the like that may or may not have resulted from the use, misuse, improper installation or operation of its systems. Purchasers sole contractual remedy is refund of the purchase price of the Omegalink system. Omegalink reserves itself the right to suspend any Weblink® account without notice and decline to offer technical support to non-Certified Technicians, non-compliant Certified Technicians or end users.

END USER TERMS OF USE

Omegalink systems are designed to remote start vehicles from a distance. In order to ensure your Omegalink system meets all safety regulations and operates as intended by the manufacturer, please follow the usage recommendations below:

• DO NOT use this system for any purpose other than its intended usage.
• DO NOT remote start a vehicle in an indoor or enclosed area (i.e. garage). Exhaust fumes are extremely dangerous and can cause personal injury or death. Install carbon monoxide detectors in every living area that can be exposed to vehicle exhaust fumes.
• DO NOT remote start a vehicle while it is being serviced. Follow the Valet Mode procedure as outlined in your Owner’s Manual.
• DO NOT remote start a vehicle in gear.
• DO NOT remote start a vehicle with the key in the ignition.
• DO NOT remote start a vehicle left unattended with open windows, unlocked doors or open convertible top.
• DO NOT allow children handle or operate long range remotes.
• ALWAYS engage your emergency brake prior to exiting your vehicle. This may limit motion if the vehicle is accidentally started in gear.

• AVOID remote starting your vehicle while passengers or pets are on board. This may increase the risk of shifter being put in gear after vehicle has been remote started.
• AVOID parking your vehicle on an inclined surface or an area surrounded by obstacles. For manual vehicles, ALWAYS ensure the Reservation Mode sequence, as outlined in your Owner's Manual, is correctly engaged prior to the next remote start.
• AVOID delaying the inspection of your Omegalink system in the event of malfunction. Immediately contact a Certified Technician to ensure that installation or defective equipment is properly addressed.

REMOTE STARTING FROM FACTORY KEY FOB

Your Omegalink system may enable remote engine start by performing one of the following button sequences on your factory key fob:

BUTTON	FUNCTION
Press on 🔓 , 🔓 , 🔓	Start engine
Press on 🔓 , 🔓 , 🔓	Stop engine

OR

BUTTON	FUNCTION
Press on 🔓 , 🔓 , 🔓	Start engine
Press on 🔓 , 🔓 , 🔓	Stop engine

NOTE: This feature may not be supported on some vehicles. If supported, the chosen button sequence will be communicated to you by your Omegalink Authorized Dealer at the time of installation. The remote start range will be equal to your factory key fob's door lock range.

ADJUSTING ENGINE RUNTIME SETTINGS

Once remote started from your factory key fob or long-range remote, your vehicle will run for the programmed 'runtime' setting. The default runtime is 15 minutes but it can also be programmed for 3, 5, 10, 25, 30 or 35 minutes. If you wish to change your remote start runtime setting, contact your Omegalink Authorized Dealer.

KEY TAKEOVER FOLLOWING REMOTE START

The ‘key takeover’ procedure ensures that your engine does not shut down upon entering the vehicle, during the programmed remote start runtime. To prevent your vehicle from shutting down, complete the steps below within the programmed delay time (45 seconds, 90 seconds, 3 minutes or 4 minutes):

FOR STANDARD KEY VEHICLES

1. Unlock and enter vehicle
2. Close doors
3. Insert key into ignition and turn ignition to ON position
4. Press foot brake

FOR PUSH-TO-START VEHICLES

1. Unlock and enter vehicle with valid smartkey
2. Close doors
3. Press foot brake

NOTE: This feature may not be supported on some vehicles. If available, the programmed ‘key takeover’ delay time will be communicated to you by your Omegalink Authorized Dealer at the time of installation.

WHEN SERVICING YOUR VEHICLE

To ensure safety during vehicle servicing, the remote starter must be placed in ‘Valet Mode’. The ‘Valet Mode’ will disable remote start functionality. To activate or deactivate the ‘Valet Mode’, follow the instructions below:

USING THE VEHICLE KEY

1. Cycle ignition OFF/ON twice (2x) rapidly
2. Press the brake pedal three times (3x)
3. If the parking lights flash once (1x), the valet mode is ON. If the parking lights flash twice (2x), the valet mode is OFF.

REMOTE START TROUBLESHOOTING

If your Omegalink remote fails to start the vehicle, the parking lights will flash three times immediately, then flash a number of times according to the errors below:

# OF PARKING LIGHT FLASHES	DIAGNOSTIC	SOLUTION
3 + 1	Need to learn tach	
3 + 2	Key in ignition at ON position	Remove key from ignition
3 + 3	Door is open	Close door
3 + 4	Trunk is open	Close trunk
3 + 5	Brake is detected	Release brake
3 + 6	Hood is open	Close hood
3 + 7	Reservation not done (manual only)	Perform reservation procedure
3 + 8	Tach failure	Contact Authorized Dealer
3 + 9	VSS detected (vehicle in movement)	Contact Authorized Dealer
3 + 10	System is in Valet Mode	Exit Valet Mode
3 + 11	Can communication failure	Contact Authorized Dealer
3 + 12	Can communication failure	Contact Authorized Dealer
3 + 13	Bypass error	Contact Authorized Dealer
3 + 14	No Pitstop or Takeover available	Contact Authorized Dealer
3 + 15	Module overheat protection	Contact Authorized Dealer

VEHICLE SHUTDOWN TROUBLESHOOTING

If the remote start sequence has been completed and the vehicle shuts down, the vehicle’s parking lights will flash 4 times immediately, then flash a number of times according to the errors below:

# OF PARKING LIGHT FLASHES	DIAGNOSTIC	SOLUTION
4+1	No engine rev detected	Contact Authorized Dealer
4+3	Brake detected	Release brake
4+4	Hood open detected	Close hood
4+5	Engine revving over 3000 RPM	Check your accelerator pedal
4+6	Glow plug error	Contact Authorized Dealer
4+7	Vehicle speed sensor error	Contact Authorized Dealer
4+8	‘Check Engine’ light detected	Clear ‘Check Engine’ code
4+9	Low fuel detected	Add fuel
4+10	Door open detected	Close door
4+11	CAN communication failure	Contact Authorized Dealer
4+12	Key synchronisation failure	Contact Authorized Dealer
4+13	Bypass error	Contact Authorized Dealer
4+14	No Pitstop or Takeover available	Contact Authorized Dealer
4+15	Module overheat protection	Contact Authorized Dealer

LIMITED LIFETIME WARRANTY

Omega Research & Development Technologies, Inc. warrants to the original purchaser of the Omegalink product that the control module and installation harnesses shall be free of defects in material and workmanship, under normal use and circumstances, for as long as the original purchaser owns the vehicle in which it was originally installed.

In the event of any product malfunction during the Warranty period, the original purchaser must return to the Authorized Dealer where it was originally purchased with the original proof of purchase. If a malfunction is detected, the Authorized Dealer will elect to repair or replace the product at its discretion. Labor costs may be applicable and are at the discretion of the Authorized Dealer.

The Limited Lifetime Warranty is automatically void if:
• An original proof of purchase is not provided when servicing the product during the warranty period;
• The date code and/or serial number is defaced, missing, or altered;
• The Omegalink product is transferred to another vehicle;
• The vehicle in which the product was originally installed is transferred to a new owner.

Omega Research & Development Technologies, Inc. is not responsible for any damages whatsoever, including but not limited to any consequential damages, incidental damages, damages for loss of time, loss of earnings, commercial loss, loss of economic opportunity and the like that may or may not have resulted from the installation or operation of an Omegalink product.

CUSTOMER SUPPORT

For all questions regarding the functionality of your Omegalink remote start system, contact your local Authorized Omegalink Dealer. For all other questions or comments, call Omega Research & Development toll-free at 800.554.4053 or visit www.caralarm.com.